

QTY	PART NUMBER
1	VSCST-GDB-01-ENGINE BASE
1	VSCST-GDB-02A-COLUMN
2	VSCST-GDB-03-CYLINDER
1	VSCST-GDB-04A-VALVE CHEST
1	VSCST-GDB-04B-VALVE CHEST DOME
1	VSCST-GDB-05-VALVE CHEST COVER
1	VSCST-GDB-06-CYLINDER BOTTOM COVER
1	VSCST-GDB-07-CYLINDER TOP COVER
1	VSCST-GDB-08-FLYWHEEL
1	VSCST-GDB-09-CRANKSHAFT
1	VSCST-GDB-10-VALVE
2	VSCST-GDB-11-CRANKSHAFT BEARING
1	VSCST-GDB-12-TUNNELING ROD
1	VSCST-GDB-13-PISTON ROD GUIDE BLOCK
1	VSCST-GDB-14-PISTON
1	VSCST-GDB-15-VALVE GUIDE
1	VSCST-GDB-16-PISTON ROD
1	VSCST-GDB-17-VALVE ROD
1	VSCST-GDB-18-REVERSING QUADRANT
2	VSCST-GDB-19-VALVE STRAP
2	VSCST-GDB-20-INT. BRACKET
1	VSCST-GDB-21-BRACKET
1	VSCST-GDB-22-REVERSING HANDLE
1	VSCST-GDB-23-ECCENTRIC
1	VSCST-GDB-24A-RETAINER DISC
1	VSCST-GDB-24B-RETAINER DISC
1	VSCST-GDB-25-VALVE KNUCKLE
4	VSCST-GDB-26-VALVE BUSH
1	VSCST-GDB-27-INLET PIPE
1	VSCST-GDB-28-EXHAUST PIPE
1	VSCST-GDB-29-CROSSHEAD SCREW
6	VSCST-GDB-31-M10 NUT
2	VSCST-GDB-32-M10x1.5 GRUB SCREW
2	VSCST-GDB-33-M12 GRUB SCREW
1	VSCST-GDB-35-M12x1.5
3	VSCST-GDB-36-M12
1	VSCST-GDB-37-M12
2	VSCST-GDB-38-M12x1.5
4	VSCST-GDB-39-M16
4	VSCST-GDB-60-M14



