


QTY.	PART NUMBER
1	07B-17-00-1-01-SIDE FRAMES+BUFFER BEAMS
4	07B-17-00-1-02-MAIN BEARING HORN STAY
4	07B-17-00-1-03-MAIN BEARING
2	07B-17-00-1-04-TRAILING WHEEL AXLE BLOCK
4	07B-17-00-1-05-TRAILING AXLE BLOCK GUIDE
2	07B-17-00-1-06-TRAILING AXLE BLOCK LEAF SPRING
1	07B-17-00-1-07-REVERSING GEAR MOUNTING BRACKET
1	07B-17-00-1-08-CYLINDER+VALVE CHEST
2	07B-17-00-1-09-CYLINDER FRONT COVER
2	07B-17-00-1-10-CYLINDER REAR COVER
1	07B-17-00-1-11-MOTION PLATE
1	07B-17-00-1-11-MOTION PLATE
1	07B-17-00-1-12-BOILER SADDLE
1	07B-17-00-1-13-DISPLACEMENT OILER
1	07B-17-00-1-14-STEAM EXHAUST UNION
2	07B-17-00-1-15-SUSPENSION LEVER BRACKET
1	07B-17-00-1-16-REACH ROD ROCKER PIVOT
2	07B-17-00-1-17-BUFFER
1	07B-17-00-1-18-FRONT RAIL SCOOP
1	07B-17-00-1-18-FRONT RAIL SCOOP
1	07B-17-00-1-19-FOOTPLATE MOUNTING ANGLE PART-1
1	07B-17-00-1-19-FOOTPLATE MOUNTING ANGLE PART-1
1	07B-17-00-1-21-FOOTPLATE OUTSIDE COVER PLATE
1	07B-17-00-1-21-FOOTPLATE OUTSIDE COVER PLATE
2	07B-17-00-1-22-FOOTPLATE MOUNTING BRACKET
1	07B-17-00-1-23-MECH WATER PUMP
1	07B-17-00-1-24-MECH-PUMP DISCHARGE PIPE
1	07B-17-00-1-25-COUPLING
1	07B-17-00-2-01-COUPLED WHEEL+AXLE
1	07B-17-00-2-02-DRIVEN WHEEL+AXLE
1	07B-17-00-2-03-TRAILING WHEEL+AXLE
2	07B-17-00-2-04-FRONT BOGIE WHEEL+AXLE
1	07B-17-00-2-05-FRONT BOGIE FRAME
1	07B-17-00-2-06-COUPLING ROD
1	07B-17-00-2-06-COUPLING ROD
2	07B-17-00-2-07-CON-ROD
1	07B-17-00-2-08-PISTON+CROSSHEAD
1	07B-17-00-2-08-PISTON+CROSSHEAD
2	07B-17-00-2-09-SLIDE VALVE ECCENTRICS
1	07B-17-00-2-10-SLIDE VALVE + ROD
1	07B-17-00-2-10-SLIDE VALVE + ROD
2	07B-17-00-2-11-VALVE CON-ROD

QTY.	PART NUMBER
2	07B-17-00-2-12-SUSPENSION LEVER
1	07B-17-00-2-13-WEIGHSHAFT+LIFTING ARM
1	07B-17-00-2-14-REACH ROD ROCKER
1	07B-17-00-2-15-INTERMEDIATE REACH ROD
1	07B-17-00-2-16-REVERSING GEAR NUT)
1	07B-17-00-2-17-REVERSING SCREW
1	07B-17-00-2-18-REVERSING ROCKER ARM
1	07B-17-00-2-19-REACH ROD
2	07B-17-00-2-20-LIFTING LINK
2	07B-17-00-2-21-EXPANSION LINK
2	07B-17-00-2-22-EXPANSION LINK DIE BLOCK
1	07B-17-00-2-23-VALVE OUTER ECCENTRIC STRAP
1	07B-17-00-2-23-VALVE OUTER ECCENTRIC STRAP
1	07B-17-00-2-24-VALVE INNER ECCENTRIC STRAP
1	07B-17-00-2-24-VALVE INNER ECCENTRIC STRAP
1	07B-17-00-2-25-WATER PUMP ECCENTRIC SHEAVE
1	07B-17-00-2-26-WATER PUMP PISTON
1	07B-17-00-2-27-WATER PUMP ECCENTRIC STRAP
1	07B-17-00-3-01-FRONT FOOTPLATE COVER
1	07B-17-00-3-02-OUTER FOOTPLATE
1	07B-17-00-3-03-WHEEL COVERS
1	07B-17-00-3-03-WHEEL COVERS
1	07B-17-00-3-04-CABIN
2	07B-17-00-3-05-CABIN REAR SUPPORT COLUMN
2	07B-17-00-3-06-CABIN SIDE HAND RAIL
1	07B-17-00-4-01-SMOKE BOX
1	07B-17-00-4-02-CHIMNEY
1	07B-17-00-4-03-SMOKE BOX DOOR LOCK
1	07B-17-00-4-04-BOILER SHELL
1	07B-17-00-4-05-FIREBOX
1	07B-17-00-4-06-SUPER HEATER FLUE
4	07B-17-00-4-07-WATER TUBE TYPE-1
2	07B-17-00-4-08-WATER TUBE TYPE-2

QTY.	PART NUMBER
2	07B-17-00-4-09-WATER TUBE TYPE-3
1	07B-17-00-4-10-ASH PAN
1	07B-17-00-4-11-REGULATOR
1	07B-17-00-4-12-STEAM MANIFOLD+WHISTLE VALVE
1	07B-17-00-4-13-BLOWER VALVE
1	07B-17-00-4-14-BLOWER VALVE PIPE
1	07B-17-00-4-15-CHECK VALVE
1	07B-17-00-4-16-SAFETY VALVE
1	07B-17-00-4-17-WATER LEVEL GAUGE
1	07B-17-00-4-18-SAFETY VALVE DOME
1	07B-17-00-4-19-DUMMY DOME
3	07B-17-00-4-20-FIREDORR NIPPLE
1	07B-17-00-4-21-FIREDORR HINGE PLATE
1	07B-17-00-4-22-FIREDORR
1	07B-17-00-4-23-FIREDORR LEDGE
1	07B-17-00-4-24-SUPER HEATER
1	07B-17-00-4-25-BLOWER EXTNSION PIPE
1	07B-17-00-4-26-BLOW DOWN VALVE
16	07B-17-00-4-27-BOILER HAND RAIL NIPPLE
12	07B-17-00-4-28-HANDRAIL SUPPORT
2	07B-17-00-4-29-BOILER HANDRAIL
2	07B-17-00-4-30-SMOKE BOX HANDRAIL + SUPPORT
2	07B-17-00-4-31-WASH DOWN PLUG
1	07B-17-00-5-01-TENDER UNDER FRAME
12	07B-17-00-5-02-TENDER AXLE BLOCK GUIDE
6	07B-17-00-5-03-TENDER WHEEL AXLE BLOCK

QTY.	PART NUMBER
6	07B-17-00-5-04-TENDER AXLE BLOCK LEAF SPRING
2	07B-17-00-5-05-TENDER BUFFER
1	07B-17-00-5-06-TENDER RAIL SCOOP
1	07B-17-00-5-06-TENDER RAIL SCOOP
1	07B-17-00-5-07-TENDER COUPLING
6	07B-17-00-5-08-BRAKE SHOE HANGER
1	07B-17-00-5-09-TENDER VALANCE
1	07B-17-00-5-09-TENDER VALANCE
6	07B-17-00-5-10-TENDER BRAKE SHOE
1	07B-17-00-5-11-TENDER SHOE HANGER LOWER CROSS BAR
2	07B-17-00-5-11-TENDER SHOE HANGER LOWER CROSS BAR
4	07B-17-00-5-12-TENDER BRAKE CROSS BAR PULL ROD
1	07B-17-00-5-13-TENDER BRAKE LEVER CROSS BAR
1	07B-17-00-5-14-TENDER BRAKE LEVER BAR PULL ROD
1	07B-17-00-5-15-TENDER TOP STRUCTURE
1	07B-17-00-5-16-TENDER HAND BRAKE SPINDLE
1	07B-17-00-5-17-TENDER HAND BRAKE SCREW NUT
1	07B-17-00-5-18-TENDER WATER FILLER LID
1	07B-17-00-5-19-TENDER TOP RAILING
3	07B-17-00-5-20-TENDER WHEEL+AXLE
1	07B-17-00-5-21-WATER HAND PUMP MOUTING BRACKET



OTHER ABBREVIATIONS
AS = AS SHOWN
DP = DEEP
DAA= DRILL AFTER ASSEMBLY
D&TAA= DRILL AND TAP AFTER ASSEMBLY
CF = CLOSE FIT (SIZE FOR SIZE)
PF = PRESS FIT
PFAA= PRESS FIT AFTER ASSEMBLY
PCD = PITCH CIRCLE DIAMETER
RM = REAM
HEX = HEXACON, 6SIDED
CP = COMPRESSED
KNL = KNURLED
CSK = COUNTERSINK
PL = PLACES
DWL= DOWEL
SPF= SPOTFACE
(T)HESOP=(TAPPED)HOLES EQUALLY SPACED ON PCD
(T)HESOC=(TAPPED)HOLES EQUALLY SPACED ON CIRCUMFERENCE
OD = OUTSIDE DIAMETER
ID = INSIDE DIAMETER
MAX/MIN = CRITICAL DIMENSION
[SA-xxx]= SUB ASSEMBLY-xxx

SOURCE: THIS MODEL WAS DOWNLOADED FROM THE INTERNET, JOHN TOM WEBSITE. THE DRAWINGS AND WRITTEN ARTICLES WERE BY MARTIN EVANS AND WERE PUBLISHED IN THE "MODEL ENGINEER" MAGAZINE OF 1977 UNDER THE TITLE: "SOUTHERN BELLE" A NEW LOCOMOTIVE FOR GAUGE 1, L.B.S.C.R. "ATLANTIC" OF CLASS H.2".

TITLE
A COAL FIRED MODEL OF A "ATLANTIC" TYPE STEAM LOCOMOTIVE CLASS H.2 FOR 5" (127mm) GAUGE

DRAWING CONTENTS
ISOMETRIC VIEW, BILL OF MATERIALS, NOTES

PROJECT No 07B-17-00
JDW DRAUGHTING SERVICES
J.A.M. DE WAAL. 12 BRIGHTWELL STREET PAPA KURA
2110. NEW ZEALAND. PHONE: 0064 09 2988815. MOB: 0211791000 E-MAIL: dewaal@xtra.co.nz.

PROJECTION		JDWDS	MODEL SCALE: 1:11.3 (127mm/5inch)
DATE			JUNE 2022
SHEET: 02 OF 17		A2	No:07B-17-00-SHT02

PLEASE NOTE THIS IS AN "A2" SIZE SHEET

DRAWINGS ARE FOR PERSONAL USE ONLY NOT FOR COMMERCIAL PURPOSES